


Sastavni delovi kotla mTronic7000 / Boiler components mTronic7000

- | | |
|---|--|
| <ul style="list-style-type: none"> 1 UL Povratni vod kotla/Return line of the boiler 2 IZ Potisni vod kotla/Starting line of the boiler 3 Sud kotla/ Exchanger of the boiler 4 Električni grejači/Electric heaters 5 Ekspanziona posuda Zilio 8/Expansion container Zilio 8 6 Cirkulaciona pumpa/Pump Wilo Para MSL/6-43/SC 7 Automatski odzračni ventil (integrisan na pumpi)/ Valve for discharging of air (on the pump) 8 Sigurnosni ventil 3bar (integrisan na pumpi)/ Safety valve 3 bar (on the pump) 9 Ispusna slavina (integrisana na pumpi)/ Drain faucet (on the pump) 10 Automatski odzračni ventil (na sudu kotla)/ Automatic air discharger (on the exchanger of the boiler) 11 Automatski osigurači sa daljinskim okidačem (sigurnosni sklop)/ Automatic fuses | <ul style="list-style-type: none"> 12 Pomoćne klembe za sobni termostat, senzor temperature bojlera, motori ventil/Clamp for thermostat, boiler temperature sensor, motor valve 13 Mrežna ploča MMB2408_VX4/Network board MMB2408_VX4 14 Relejna ploča PLR_V3B/Relay board PLR_V3B 15 Senzor temperature kotla (KTY81-110)/Boiler temperature sensor (KTY81-110) 16 Sigurnosni termostat 95 °C (NO)/Safety thermostat 95 °C (NO) 17 Sklop procesorske ploče sa displejem (EK_CPU_1_3)/ Control panel with display (EK_CPU_1_3) 18 Elastično crevo za priključenje expansione posude/ Elastic hose for connection of expansion vessel 19 Elastično drenažno crevo odzračnog ventila/ Elastic drainage hose of valve for discharging of air 20 Elastično drenažno crevo sigurnosnog ventila/ Elastic drainage hose of safety valve 21 Prekidač/switch (ON/OFF) 22 Senzor hidrauličnog pritiska (integrisan na pumpi)/ Hydraulic pressure sensor (on the pump) |
|---|--|



Slika/Image: Izgled otvorenog uređaja/
Appearance of an open device